burkert FLUID CONTROL SYSTEMS



Flowmeter for the continuous measurement of water

- · Ultrasonic flowmeter using transit time method
- Dynamic range ≥ 1:250
- Low pressure drop
- No flow-settling section necessary in the inlet or outlet





Product variants described in the data sheet may differ from the product presentation and description.

Can be combined with

wheel





Type 8611 • eCONTROL - Universal controller



Type 8802

ELEMENT continuous control valve systems - overview



Type 8619 → multiCELL - Multi-channel and multi-function transmitter/controller

Type description

The Type 8081 ultrasonic flowmeter is intended for the flow measurement of water which may be slightly charged with contaminants. It consists of an electronic module and a brass fitting with a built-in measuring tube. In combination with a controller and a control valve, it enables very simple flow control loops to be established. The electrical connection is made via a 5 pin M12 fixed connector.

The flowmeter features, depending on the version:

- · a pulse output or
- a pulse output and a 4...20 mA current output.

Each version is available for 5 different flow ranges:

- model QN 0.6 DN15: 0.06 to 20 l/min (nominal flow rate 0.6 m³/h namely 10 l/min)
- model QN 1.5 DN15: 0.1 to 50 l/min (nominal flow rate 1.5 m³/h namely 25 l/min)
- model QN 2.5 DN20: 0.16 to 82 l/min (nominal flow rate 2.5 m³/h namely 41 l/min)
- model QN 3.5 DN25: 0.6 to 116 l/min (nominal flow rate 3.5 m³/h namely 58 l/min)
- model QN 6.0 DN25: 1 to 200 l/min (nominal flow rate 6.0 m³/h namely 100 l/min)



Table of contents

1.	Ger	neral Technical Data	3
2.	Арр	provals	4
	2.1.	Pressure Equipment Directive	.4
		Device used on a pipe	.4
3.	Mat	terials	5
	3.1.	Chemical Resistance Chart – Bürkert resistApp	.5
	3.2.	Material specifications	
4.	Dim	nensions	5
5.	Per	formance specifications	6
	5.1.	Measurement deviation diagram	.6
6.	Pro	duct installation	6
	6.1.	Installation notes	.6
7.	Pro	duct operation	7
	7.1.	Measuring principle	.7
8.	Ord	lering information	7
	8.1.	Bürkert eShop – Easy ordering and quick delivery	.7
	8.2.	Bürkert product filter	
	8.3.	Ordering chart	.8
	8.4.	Ordering chart accessories	.8



1. General Technical Data

Note:

If the device is mounted in a humid environment or outside, then the maximum voltage allowed is 35 V DC instead of 36 V DC.

Product properties					
Material	and a second Palace Palace (C. S.).				
	are compatible with the fluid you are using. apter "3.1. Chemical Resistance Chart – Bürkert resistApp" on page 5.				
Non wetted parts					
Housing	PPS				
Cover	PA				
Screws	Stainless steel				
Fixed connector M12	Silicone				
Wetted parts					
Fitting	Brass				
Measuring tube	PES				
Seal	EPDM				
Dimensions	Detailed information can be found in chapter xxx.				
Measuring element	2 ultrasound emitter-receiver cells				
Measuring range	0.06200 l/min				
Pipe diameter	DN15DN25				
Performance data					
Measurement deviation	Flowrate: ≤(0.01% of full scale +2% of measuring value)¹.) Detailed information can be found in chapter "5.1. Measurement deviation diagram" on				
	page 6.				
Repeatability	≤1%				
Electrical data					
Operating voltage (V+)	1236 V DC				
Current consumption	Own consumption: <4 mA				
·	Consumption with load: <1 A				
Output signal	The device is available with a pulse output or with a pulse output and a 420 mA ana-				
Caspat o.g. ia.	logue outputs				
	Device with a pulse (transistor) output:				
	 Pulse (transistor): NPN (as default setting) or PNP (on request), open collector 				
	NPN-output: 0.236 V DC, max. 700 mA, min. 5 mA				
	Galvanic insulation and protected against overvoltage, polarity reversals and				
	short circuit				
	Device with a pulse (transistor) and a 420 mA analogue outputs:				
	 Pulse (transistor): PNP (as default setting) or NPN (on request), open collector 				
	PNP-output: operating voltage (V+), max. 700 mA				
	Galvanic insulation and protected against overvoltage, polarity reversals and				
	short circuit				
	- Current: 420 mA (sourcing mode and PNP transistor as default setting, sinking				
	mode and NPN transistor on request)				
	Loop impedance max.: 1100 Ω at 36 V DC; 610 Ω at 24 V DC;				
	100 Ω at 12 V DC				
Scaling	Pulse (transistor):				
	If model QN 0.6 or QN 1.5: 1 pulse corresponds to a volume = 0.002 l				
	(K factor = 500 pulse/litre)				
	If model QN 2.5 or QN 3.5 : 1 pulse corresponds to a volume = 0.005 l				
	(K factor = 200 pulse/litre)				
	 If model QN 6: 1 pulse corresponds to a volume = 0.01 I 				
	(K factor = 100 pulse/litre)				
	 Current: 4 mA correspond to 0 l/min and 20 mA correspond to Q_{max} of flow range (by default) 				
Voltage supply cable	1.5 mm² max. cross-section				
Media data					
Temperature	+5+90 °C (+41+194 °F)				

Visit product website ▶ 3 | 9



Pressure	PN16 (232.16 PSI)					
Process/Port connection & communication						
Process connection	G or NPT external thread; ¾", 1" or 1"¼					
Electrical connection	5 pin M12 male fixed connector for female 5 pin M12 cable plug (not provided)					
Approvals and certificates						
Standards						
Protection class according to IEC/ EN 60529	IP65 with M12 cable plug plugged-in and tightened					
Directives						
CE directives	The applied standards, which verify conformity with the EU Directives, can be found on the EU Type Examination Certificate and/or the EU Declaration of conformity (if applicable					
Pressure equipment directives	Complying with Article 4, Paragraph 1 of 2014/68/EU directive Detailed information on the pressure equipment directive can be found in chapter "2.1. Pressure Equipment Directive" on page 4.					
Certificate	On request:					
	Test report 2.2					
	Calibration certificate					
Environment and installation						
Ambient temperature	Operating and storage: +5+55 °C (+41+131 °F)					
Relative air humidity	≤80 %, without condensation					
Height above sea level	Max. 2000 m					

^{1.)} Under reference conditions i.e. measuring fluid = water, ambient and water temperature = 20 $^{\circ}$ C (68 $^{\circ}$ F).

2. Approvals

2.1. Pressure Equipment Directive

The device conforms to Article 4, Paragraph 1 of the Pressure Equipment Directive 2014/68/EU under the following conditions:

Device used on a pipe

Note:

- The data in the table is independent of the chemical compatibility of the material and the fluid.
- PS = maximum admissible pressure, DN = nominal diameter of the pipe

Type of fluid	Conditions
Fluid group 1, Article 4, Paragraph 1.c.i	DN ≤25
Fluid group 2, Article 4, Paragraph 1.c.i	DN ≤32 or PS*DN ≤1000
Fluid group 1, Article 4, Paragraph 1.c.ii	DN ≤25 or PS*DN ≤2000
Fluid group 2, Article 4, Paragraph 1.c.ii	DN ≤200 or PS ≤10 or PS*DN ≤5000

Visit product website ▶ 4 | 9



3. Materials

3.1. Chemical Resistance Chart - Bürkert resistApp




Bürkert resistApp - Chemical Resistance Chart

You want to ensure the reliability and durability of the materials in your individual application case? Verify your combination of media and materials on our website or in our resistApp.

Start Chemical Resistance Check

3.2. Material specifications




No.	Element	Material	
1	Screws	Stainless steel	
2	Cover	PPS	
3	M12 fixed connectors	PA	
4	Seal	Silicone	
5	Housing	PPS	
6	Fitting and measuring tube (inside fitting)	Brass and PES	
7	Seal	EPDM	

4. Dimensions

Note:

Specifications in mm




DN	Α	В	Н	h	L1	L2	L3	L4	L5
15	G or NPT ¾"	65.5	76.5	14.5	110	90	67	6.5	19.5
20	G or NPT 1"	65.5	79.0	18.0	130	90	67	6.5	19.5
25	G or NPT 11/4"	65.5	83.5	23.0	260	90	67	6.5	19.5



5. Performance specifications

5.1. Measurement deviation diagram




6. Product installation

6.1. Installation notes


Note:

- The flowmeter is not designed for gas and steam flow measurement.
- Minimum straight upstream and downstream distances are not necessary.

The correct direction of fluid flow in the pipe is indicated with an arrow, engraved on the underside of the fitting.




The flowmeter can be installed into either horizontal or vertical pipes. When horizontally mounted, the max. fluid temperature is 90 °C. The max. fluid temperature must be reduced to 80 °C when the electronic (black enclosure) is turned upwards. When vertically mounted the max. fluid temperature is also 80 °C.





The 8081 works correctly when the pipe is full and free of any air bubbles near the flowmeter. In presence of bubbles in the pipe, the left installation no.1 should be avoided.



If the absence of any air bubbles cannot be guaranteed, the device should be fitted on a horizontal pipe, with the electronic enclosure facing down. This way, the bubbles will not interfere with the propagation of ultrasound waves.




It is equally advisable to place stop valves before and after the flowmeter, in order to facilitate the assembly and disassembly of the latter.



7. Product operation

7.1. Measuring principle

The 8081 ultrasonic flowmeter is based on the transit time method. The sound transit time from emitter 1 to receiver 2 will be measured and compared with the transit time from emitter 2 to receiver 1. The difference in transit time is directly proportional to the flow speed of the fluid.



The electronic module delivers a pulse signal proportional to the volume or an industry standard 4...20 mA signal, proportional to the flow rate.

8. Ordering information

8.1. Bürkert eShop - Easy ordering and quick delivery



Bürkert eShop - Easy ordering and fast delivery

You want to find your desired Bürkert product or spare part quickly and order directly? Our online shop is available for you 24/7. Sign up and enjoy all the benefits.

Order online now



8.2. Bürkert product filter



Bürkert product filter - Get quickly to the right product

You want to select products comfortably based on your technical requirements? Use the Bürkert product filter and find suitable articles for your application quickly and easily.

Try out our product filter

8.3. Ordering chart

Model	DN	Flow range	Process connection	Outputs	Article no.
QN 0.6	15	0.0620 l/min	External thread G 3/4"	Pulse, NPN	560131 ≒
				Pulse, PNP +420 mA as source	560113 ≒
			External thread NPT 3/4"	Pulse, NPN	560612 ≒
				Pulse, PNP +420 mA as source	560617 🛱
QN 1.5	15	0.150 l/min	External thread G 3/4"	Pulse, NPN	559865 ≒
				Pulse, PNP +420 mA as source	559868 🛱
			External thread NPTx¾"	Pulse, NPN	560613 ≒
				Pulse, PNP +420 mA as source	560618 🖼
QN 2.5	20	0.1682 l/min	External thread G 1"	Pulse, NPN	559866 🛱
				Pulse, PNP +420 mA as source	559869 🛱
			External thread NPT 1"	Pulse, NPN	560614 🛱
				Pulse, PNP +420 mA as source	560619 🛱
QN 3.5	25	0.6116 l/min	External thread G 1"1/4	Pulse, NPN	559867 🖼
				Pulse, PNP +420 mA as source	559870 🛱
			External thread NPT 1"1/4	Pulse, NPN	560615 ≒
				Pulse, PNP +420 mA as source	560620 ≒
QN 6.0	25	1200 l/min	External thread G 1"1/4	Pulse, NPN	560132 ≒
				Pulse, PNP +420 mA as source	560114 🛱
			External thread NPT 1"1/4	Pulse, NPN	560616 ≒
				Pulse, PNP +420 mA as source	560621 ≒

8.4. Ordering chart accessories

Description	Article no.
5 pin M12 female cable plug moulded on cable (2 m, shielded)	438680 ∖≖
5 pin M12 female cable plug with plastic threaded locking ring	917116 😕

Bürkert - Close to You

